

30-DAY RETURNS





MANUALS AND SPECIFICATION SHEETS FROM OVER 200 MANUFACTURERS - OVER 65000 PDF FILES & GROWING

Bosch B930: Data Sheet

Manufacturer: Bosch Security

Product Type: ATM Style-alpha Numeric Keypad

Manufacturer Part Number: B930

General Information

Harmonization Code: 8537103000

· Country of Origin: CN

· Type: Hardwired

Keypads: Alphanumeric

Related Links (Right click to open in new tab)

Visit the <u>B930</u> product page for detailed information

View over 1264 other Bosch products

View list of all the other manufacturers we carry

Require Multiple Quantities? Email us for Bulk Pricing

Scroll down to view the Bosch B930 Data Sheet



https://www.alldataresource.com currently stocks over 220,000 items from over 240 brands and can special order many more.

For over 10 years, we have earned the confidence of our customers by providing professional service and support.

If you need technical support or asistance, you can email us at sales@alldataresource.com at any time.



B930 ATM Style Alphanumeric Keypad (SDI2)

www.boschsecurity.com





point, user, and area names
 Simple menu-style user interface with dedicated function buttons for common commands

▶ 5-line ATM style LCD display with up to 32 character

- function buttons for common commands

 Programmable keypad shortcuts and situation
- Programmable keypad shortcuts and situation sensitive on-screen help makes system operation simple and easy
- ► Highly visible on (arm)/alarm, ready to turn on (arm), power and gas alarm indicators
- ► Simple installation with self-locking base and chassis design, plus built-in bubble level

The B930 ATM Style Alphanumeric Keypad (SDI2) is a SDI2 bus compatible device. Each keypad has user adjustable options such as volume and brightness. The B930 shows five-line system messages for all areas.

System overview

- For commercial use, install the keypad in building entrances and areas with unrestricted access.
 Mounting a keypad near exterior doors in hotel or business lobbies allows people to identify the type and location of the emergency.
- For residential use, install the keypad near the front and rear entrances to the home. Install additional keypads in a kitchen or in a bedroom.
- Use multiple keypads in a large building with many separate areas of security. Program multiple keypads to control multiple areas.
- Audible tones from the keypad sounder alert personnel to fire events and assist fire fighters in locating the keypad.

Functions

LCD Display

The keypad uses words, numbers, and symbols to show the status of the security system. When several events occur, the keypad shows each event in order of priority. The display shows five lines, 21 characters per line.

Keys

Each keypad has 10 numeric keys, one function [CMD] key, keys for previous, next, escape, and help, and eight softkeys. When pressed, keys enable keypad backlighting and emit a muted beep. Use the eight softkeys to select a menu and associated functions.

I FDs

The status LEDs on the keypad provide a quick visual reference for system status.

✓	The system is ready to turn on (arm)
A	The system is on (armed)
\triangle	Indicates there is a trouble condition
GAS	Indicates the presence of dangerous gases including carbon monoxide (NFPA 720)
#	Indicates that the system has power.

Audible tones

The keypad has a built-in speaker that produces several distinct warning tones. The keypad backlight illuminates when it emits an audible tone. You can use a passcode to silence the tone.

The tones include:

- Fire signal. When an area is in fire alarm, the keypad emits a pulsed, high-pitched bell tone.
- Gas signal. When a gas point activates, the keypad emits a unique high pitched tone.
- User alarm. When a user alarm (such as panic and medical alarms) occurs, the tone sounds for the programmed amount of time.
- Burglary signal. When an area is in alarm, the keypad emits a steady, high pitched bell tone.
- Entrance warning. The keypad emits an intermittent beep tone during entry delay periods to remind the user to disarm the area.
- Exit warning. The keypad emits an intermittent beep tone during exit delay.
- Invalid button buzz. When an invalid button, or sequence of buttons, is pressed, the keypad emits a flat buzz tone.
- Keypad encoding tone. The keypad emits a muted beep tone as each button is pressed to indicate that the entry was accepted.
- Trouble buzzer. When a trouble event occurs, such as a service alert, the keypad emits a two-tone warble until you enter a programmed passcode with the appropriate authority.
- Watch tone. A single clean tweedle tone alerts the user anytime a watch point is faulted.

Certifications and approvals

Region	Certifica	tion
USA	UL	NBSX.S1871, NBSX7.S1871, UTOU.S1871, UTOU7.S1871, AMCX.S1871, AMCX7.S1871, AMTB.S1871, ANET.S1871, AOTX.S1871, AOTX7.S1871, APAW.S1871, APAW7.S1871, APOU.S1871, APOU7.S1871 [UL & cUL]
	CSFM	7167-1615:0247 7167 CONTROL UNIT (HOUSEHOLD)

Installation/configuration notes

Compatible control panels

B5512

B4512

B3512

GV4 Series firmware v2.00 and higher

Mounting considerations

Mount in indoor dry locations.

Power supply

A compatible control panel supplies the power and data requirements to the keypad through a four-wire connection.

Enclosure and wiring

The sliding self-locking enclosure has an integrated bubble level and custom gap-free, lift-gate style terminal blocks to make installation easier.

Parts included

Quant.	Component
1	Keypad
1	Hardware pack
1	Installation Guide

Technical specifications

Wiring

Terminal wires	12 AWG to 22 AWG (2 mm to 0.65
	mm) wire

Environmental considerations

Relative humidity	5% to 93% at +32°C (+90°F) non- condensing
Temperature (operating)	0°C to +50°C (+32°F to +122°F)

Keypad

Dimensions	6.2 in x 5.5 in x 1 in (158 mm x 140 mm x 26 mm)
Weight	14.1 oz (0.40 kg)
Material	Acrylonitrile butadiene styrene (ABS) Poly(methyl methacrylate) (PMMA)
Display window	5 line display 21 characters per line
Indicators	Illuminated keys Status LEDs Warning and indicating tones

Power requirements

Current	35 mA in standby mode 80 mA in alarm mode
Voltage (input)	12 VDC nominal

Trademarks

All hardware and software product names used in this document are likely to be registered trademarks and must be treated accordingly.

Ordering information

B930 ATM Style Alphanumeric Keypad (SDI2)

Five-line ATM style alphanumeric keypad Order number **B930**

Accessories

B96 Keypad Trim Bezel

Cover the wall footprint of previous keypads when replacing them with the new, slim design of B930 and B920 keypads. The white trim bezel is (8.6 in x 6.3 in x 1.2 in (22 mm x 16 mm x 3 mm).

Order number B96

Represented by:

Americas:

Bosch Security Systems, Inc. 130 Perinton Parkway Fairport, New York, 14450, USA Phone: +1 800 289 0096 Fax: +1 585 223 9180 security.sales@us.bosch.com www.boschsecurity.us

Europe, Middle East, Africa:

Bosch Security Systems B.V. P.O. Box 80002 5617 BA Eindhoven, The Netherlands Phone: + 31 40 2577 284 Fax: +31 40 2577 330 emea.securitysystems@bosch.com www.boschsecurity.com

Asia-Pacific:

Robert Bosch (SEA) Pte Ltd, Security Systems 11 Bishan Street 21 Singapore 573943 Phone: +65 6571 2808 Fax: +65 6571 2609 apr.securitysystems@bosch.com www.boschsecurity.asia

China:

Bosch (Shanghai) Security Systems Ltd. 201 Building, No. 333 Fuquan Road North IBP Changning District, Shanghai 200335 China Phone +86 21 22181111 Fax: +86 21 22182398 www.bossbecurity.com.cn

America Latina:

Robert Bosch Ltda Security Systems Division Via Anhanguera, Km 98 CEP 13065-900 Campinas, Sao Paulo, Brazil Phone: +55 19 2103 2860 Fax: +55 19 2103 2862 latam.boschsecurity@bosch.com www.boschsecurity.com